




D-LUX LED DOWNLIGHTS

HOW TO CHANGE
THE DRIVER




Changing a driver

The following pages show a detailed guide on changing a D-Lux driver.

If, having followed the steps detailed on the following pages your downlight still does not function please don't hesitate to contact our remedial team on **01905 610200**.

1. The D-Lux LED Downlight is made up of 3 main parts:

- A) Downlight
- B) Driver
- C) Mains Connector





2. If your downlight isn't functioning then the first thing to check is the driver. To do this pull the downlight down from the ceiling.





3. As you pull the downlighter from the ceiling, **you must hold on to the spring loaded retaining clips** to avoid them springing back and trapping your fingers or damaging the plaster board as shown in fig. 4. Once the springs and fitting are clear from the ceiling, they can then be released gently back to their unloaded position (fig. 8).



4. Once the downlight has been removed from the ceiling, the driver will be the next out. When you have this out, you will then need to disconnect it from the mains (fig. 9, 10).



When the downlight is out of the ceiling, disconnect the driver from the mains (fig. 11, 12).



5. To attach the new driver follow the instructions in Stage 4 in reverse, making sure the driver is re-attached to the mains and then re-attached to the downlight. Once you have done this put the fitting back in the ceiling.
6. To put the fitting back in the ceiling follow the instructions for stage 3 in reverse.

Just before placing the downlight back in the ceiling make sure the spring loaded retaining clips are placed in the ceiling first, before the rest of the fitting goes in (fig. 13). This is to ensure that the downlight doesn't fall straight back out of the ceiling. The downlight can then be pushed gently back into its original position.



When all previous steps completed turn the electricity back on and check if your downlight is now functioning.

If your downlight does not work please contact GL on 01905 610200 for a replacement driver.

If after changing the driver your downlight still doesn't function, then it is likely that there is a wiring issue, in which case you should contact your housebuilder customer care team.



For product information visit

www.gl-e.uk

or e-mail **sales@gl-e.uk**

For all information call **01905 610200**